

Think & Work
Professionally

User Manual



دفترچه
راهنما

TOSAN®

PROFESSIONAL TOOLS



0071 D

300 W - 6.5 mm



0002 D

400 W - 10 mm



0002 Da

400 W - 10 mm



0022 D


750 W - 13 mm

0022 D BMC



0022 Da

750 W - 13 mm



0034 D

1050 W - 13 mm

0034 Db

Drills & Impact Drills

Table of contents

Title	Page
How to use the manual	1
General safety	1
User safety	1
Electrical safety	2
Work area safety	2
Correct operation	3
Technical specification	6
Products description	7
Product component	15
Operation	15
Carry and transportation	16
Storage / disposal	16

How to use the manual

The reason to published and provide this manual is to let the user how to use the product in correct way and also within this manual, provide you how to keep safety and operation of product.

So recommend you to always keep this manual read before get start the operation with the tool and always keep beside you during working.

In the case of any services or emergency cases need, just refer to the part of after sales services and guaranty card which come beside with the manual of this product.

General safety

The meaning of tool, means power tools.

Keep carefully read the signs and safety icons which indicated in this manual and make them to understand well. If avoid to learn and understand the safety and operation of product well, will cause of happening injuries and bad disease.

User safety

Before get start working with this tool, become assure that you are able to work with this tool. Start your operation with high accuracy, any usage without mention and notice will cause of serious injuries.

Always use standard safety equipment. Using safety goggles, clothes, gloves, mask and ... will reduce the case of injuries and danger.

Before leave the machine, be careful that it becomes completely turned off and out of working then leave in safe place.

Always use the standard accessories in correct way and be careful when they are ready to work.

In order to have better controlling on the machine, be careful about your working situation and place. This would be cause of better operation and safe working with the tool.

Before get plug in the machine, be sure that the switch didn't turn ON.

In the case of any defects and problem of tool because of bad transportation or non-standard using, always refer to the official after sales services center.

Electrical safety

Always choose socket which is suitable to the plug of this tool and never make any change on plug and don't transfer the plug to use with other devices and machines. Otherwise will cause of electrical dangers and shocks.

During working with this tool, never touch your body with any other electrical appliance like TV, refrigerator and radiator.

Avoid to place the tool in wet and rainy places and surfaces, in the case of coming any water to the product, will cause of electrical shocks and defects to the product.

Never use the cord to take out the plug from the socket.

Always put away the cord and cable from any heating places or sharp objects.

Always become sure about the cable safety, damaged cable and cord will cause of electric shocks.

Always use extension cord in the case of using the product in wide places, like outdoors.

Working place safety

Enough brightness in place, would be cause of better and visible working.

Never ever use product in place which contained explosion liquid, gas and....

Correct operation

Because of each machine and product power limitation, always use the product for the suitable power and loading, otherwise will cause of damages and defects to the product. Never use the product and tool for multi purposes. As each machine and product designed for a specific job and working condition.

Avoid any falling and throwing the product because of sensitive parts and components inside the product.

Never use the product by non-skilled persons.

Before get start working, always keep fully read the manual.

Most important purpose of this tool, is to use as drilling different surfaces.

Before get start and operate the product, become sure about the bits which must be fasten firmly in the chuck and also the ruler of machine and auxiliary handle.

Before get start working with the tools, firstly check the machine condition and also safety of product.

In the case of using product, firstly turn ON the machine and let the speed become normal. Never get start working the machine when it place on working surfaces. This will cause of happening injuries to the user and defects on product.

In the case of any problem and defect to the switch or burning smells or power cut, only get the machine turn OFF and call TOSAN official after sales services center.

Always keep and hold the product firmly in your hands, in order to avoid happening any vibration.

Always take care of product housing and handle from any grease and lubricant.

Long time using such product which has got big pressure come to machine, will cause of get the user hand tired.

Never turn on the machine, when it is not necessary to use without any loading.

Using non-standard and low quality bits, will cause of coming big pressure to the machine and will cause of damaged to the product.

How to use drill machine

Always take note to the voltage rate, the supply power voltage always must be meet the product specification.

Always select and choose suitable bits.

Fit firmly the chuck key inside the hole of chuck and start to rotate anticlockwise in order to open the chuck mouth in order to fit with the bit shank diameter.

Before get start drilling be sure about the surface and place which must be fix very strongly.

Before get start drilling, first the surface must be make small hole with the special tool (small bit) in order to let the hole ready for drilling. This would be avoid any shaking or losing the bits on surface.

Get plug in machine to the power supply socket.

In order to get well operation of machine, refer to the need working condition, the rotation of chuck can be adjust by the left/right rotation changing knob. Always from drilling, set the condition on right side.

Place the bit and hold the machine on the hole which need to drilling, then push the switch. Also be careful about speed which must be set according to the bit size and surface material.







At the beginning, drilling must be start with smooth and balance pressure. When the bit going to come out from other side of the surface, lower down the speed. When the hole completely drilled, still push the switch and drilling in order to take out the bit from the hole, this would be help to take out the bit from the hole smoothly.


NOTICE: be careful about the small sizes bits, during drilling the speed must be very slow and smooth.

Using not suitable and low quality cutting and grinding disc, will be cause of extending the time of your operation and also coming too much tension to the product.

Product life time standard, depends on how to use and also how to care the product. Defiantly non-standard working and using fake spare parts. Always choose and use suitable and standard spare parts, this would be guaranty the product standard life time.

Model Parameter	0071 D	0002 D	0002 Da	0022 D	0022 D BMC	0022 Da	0034 D	0034 Db
Output power (W)	300	400	400	750	750	750	1050	1050
No Load speed (min ⁻¹)	0-3800	0-2700	0-2700	0-2800	0-2800	0-2800	1200 2880	1200 2880
Number of beats	–	–	–	44800	44800	44800	19200 44800	19200 44800
Chuck size (mm)	0.5-6.5	1.5-10	1.5-10	1.5-13	1.5-13	1.5-13	1.5-13	1.5-13
Max drilling diameter in wood (mm)	10	20	20	30	30	30	40	40
Max drilling diameter in steel (mm)	6.5	10	10	13	13	13	13	13
Max drilling diameter in concrete (mm)	NO	NO	NO	16	16	16	20	20
Weight (Kg)	1,1	1,4	1,4	2,1	2,1	2	2,9	2,9



0071 D

1- ON/OFF switch

2- Switch lock knob

3- Left/right rotation changing knob


4- Key chuck

5- Air intake slots

6- Air vent slots

7- Cord sleeve


0002 D



- 1- ON/OFF switch
- 2- Speed dimmer switch
- 3- Switch lock knob

- 4- Key chuck
- 5- Air intake slots
- 6- Air vent slots

- 7- Left/right rotation
changing knob
- 8- Cord sleeve


0002 Da

- 1- ON/OFF switch
- 2- Speed dimmer switch
- 3- Switch lock knob

- 4- Keyless chuck
- 5- Air intake slots
- 6- Air vent slots

- 7- Left/right rotation changing knob
- 8- Cord sleeve


0022 D



- 1- ON/OFF switch
- 2- Speed dimmer switch
- 3- Switch lock knob
- 4- Key chuck

- 5- Air intake slots
- 6- Air vent slots
- 7- Left/right rotation changing knob
- 8- Auxiliary handle

- 9- Depth indicator ruler
- 10- Changing function knob (drilling / impacting)
- 11- Cord sleeve


0022 D BMC

- 1- ON/OFF switch
- 2- Speed dimmer switch
- 3- Switch lock knob
- 4- Key chuck

- 5- Air intake slots
- 6- Air vent slots
- 7- Left/right rotation changing knob
- 8- Auxiliary handle

- 9- Depth indicator ruler
- 10- Changing function knob (drilling / impacting)
- 11- Cord sleeve


0022 Da



- 1- ON/OFF switch
- 2- Speed dimmer switch
- 3- Switch lock knob
- 4- Keyless chuck

- 5- Air intake slots
- 6- Air vent slots
- 7- Left/right rotation changing knob
- 8- Auxiliary handle

- 9- Depth indicator ruler
- 10- Changing function knob (drilling / impacting)
- 11- Cord sleeve


0034 D

- 1- ON/OFF switch
- 2- Speed dimmer switch
- 3- Speed change knob
- 4- Switch lock knob

- 5- Changing function knob
(drilling / impacting)
- 6- Key chuck
- 7- Depth indicator ruler
- 8- Axillary handle

- 9- Air income slots
- 10- Air vent slots
- 11- Left/right rotation
changing knob
- 12- Cord sleeve

0034 Db



- 1- ON/OFF switch
- 2- Speed dimmer switch
- 3- Speed change knob
- 4- Switch lock knob

- 5- Changing function knob
(drilling / impacting)
- 6- Key chuck
- 7- Depth indicator ruler
- 8- Axillary handle

- 9- Air income slots
- 10- Air vent slots
- 11- Left/right rotation
changing knob
- 12- Cord sleeve

Before get start

Chuck: this part is to fix and place the bits, power bits and ... on machine.

ON/OFF Switch: this switch designed to turn machine power ON/OFF, push to turn machine ON and when release the power turn to OFF.

Left/right rotation changing knob: with this knob, can change the rotation side of chuck

Speed dimmer knob: by using this knob, easily can change the speed rotation of chuck.

Switch lock knob: in order to keep machine running and hold to ON condition, press this knob when the machine turn to ON, so in this way machine will working continuously. In order to get the machine turn to OFF from this condition, press 1 time the switch.

Changing function knob drilling/impacting: by changing the condition of this knob, you can shift between drilling and impacting, choose 1 of them to operate. So in the case to drilling on wood and steel, condition must be set on drilling for drilling on stone or concrete, choose the impacting function.

Speed change knob: this knob designed on model 0034 D which can be operate on this machine.

Operation

After place the bit inside the chuck, then plug in and turn the machine to ON condition. In order to save power and energy, only in case of need working with machine, plug in socket. Always use high quality drilling bits to have more comfort and smooth operation. This would be increase the life time of machine.

No need to add any grease or oil inside the machine after daily working.

Carry and transportation

Before any carrying or moving the machine, firstly pull out the plug from socket. Never use the cable to carry the machine. In the case of carrying the product, recommend you to keep the box of product, it would be helpful for easier carrying of machine.

Product storage / disposal

Always keep clean the product, specially the slots on housing, this would be protect the machine from any dust or oil which may come inside from the out of machine. Never use detergent or acidic liquid to clean the product, will be cause of defect to the housing.

In case of storage in ware house, always keep protect the product inside the carton box and keep away from humid or wet places. After 6 month no use, before get start, first refer to the official after sales services center for maintaining the product.

Based on international regulation for recycle the power tools, the accessories and other parts of this product must be keep observe to do same as regulation. Although after the product get defected or old, some inside parts and components can be workable and usable.

حمل و جابجایی ابزار

پیش از جابجایی ابزار، آن را از برق جدا نمایید. هرگز از کابل دسـتگاه، برای حمل و جابجایی استفاده نکنید.
توصیه می‌شود که جعبه ابزار را نگه دارید، زیرا به هنگام جابجایی دستگاه، وجود آن بسیار مفید خواهد بود.

نگهداری در شرایط انبار/فصول مختلف سال/شرایط اسقاط کردن محصول

همواره تمامی قسمت‌های ابزار به خصوص شیارهای تهویه را تمیز نگه دارید و غبار روی دستگاه را پاک کنید. این کار از ورود غبار و مواد خارجی به دستگاه جلوگیری می‌کند. هرگز برای تمیزکاری از محلول‌های خورنده استفاده نکنید؛ زیرا به پوسته ابزار آسیب می‌رساند.

جهت نگهداری ابزار در شرایط انبار، ابزار را درون جعبه مخصوص قرار داده و دور از محیط‌های مرطوب و باران و برف قرار دهید. برای استفاده مجدد از دستگاه، بعد از مدت بیش‌تر از ۶ ماه، ضمن مراجعه به خدمات پس از فروش، اقدام به سرویس‌کاری ابزار نمایید.

ابزار برقی، متعلقات و بسته‌بندی آن، می‌بایست مطابق با مقررات حفظ محیط زیست از رده خارج و بازیافت شود.

ابزار برقی، متعلقات و بسته‌بندی آن، در هنگام بازیافت باید از هم جدا شوند.
ابزارهای برقی و متعلقات آن‌ها، در پایان عمر کاری خود، همچنان دارای مواد ارزشمندی هستند که می‌تواند وارد چرخه کاری شود.

قبل از شروع

سه نظام: از این قطعه جهت نصب مته، سرپیچ گوه‌شکنی و... مناسب استفاده می‌شود.

کلید روشن/خاموش: همان‌طور که از نام آن پیداست، از این کلید برای روشن و خاموش کردن دستگاه استفاده می‌شود. به‌طوری که با فشردن آن به سمت داخل، دستگاه روشن و با رها کردن آن دستگاه خاموش می‌گردد.

شستی چپگرد- راستگرد: با استفاده از این کلید می‌توان جهت چرخش سه نظام را عوض کرد.

کنترل سرعت (دیمر): با استفاده از این کلید می‌توان به صورت الکترونیکی، سرعت چرخش سه نظام را متناسب با نوع کاربری کنترل کرد. کنترل سرعت (دیمر)، در همه دریل‌های توسن به جز مدل ۰۰۷۱D به صورت ولوم روی کلید در نظر گرفته شد و اما در مدل، ۰۰۷۱D اصطلاحاً به صورت گازی است.

قفل کن کلید: جهت تثبیت حالت روشن دستگاه می‌توان از این قفل کن استفاده نمود. بدین منظور، پس از روشن کردن دستگاه، قفل کن را فشار دهید تا دستگاه به‌طور دائم روشن بماند. برای خاموش کردن ابزار کافی است که کلید سوئیچ را یکبار فشار دهید.

اهرم تغییر حالت (دریل/دریل چکشی): این اهرم عملکرد دریل را در یکی از دو وضعیت دریل یا دریل چکشی قرار می‌دهد. بدین منظور جهت سوراخ کاری چوب و فلز، از حالت دریل و برای سوراخ کاری دیوار و سطوح بتنی، از حالت دریل چکشی (ضربه‌ای) استفاده می‌شود.


اهرم تغییر دور (سرعت): در دریل مدل ۰۰۳۴D، جهت تنظیم سرعت متناسب با کاربری، اهرم تغییر دور (سرعت) در نظر گرفته شده است.

راه اندازی

پس از نصب مته، کابل ابزار را به منبع جریان برق وصل نموده و کلید را فشار دهید. جهت صرفه‌جویی در مصرف برق، دستگاه را فقط در زمان مورد نیاز به استفاده از آن، روشن ننمائید.


توصیه می‌گردد جهت سهولت در کار، از مته با کیفیت و تیز استفاده نمائید، این امر موجب افزایش طول عمر دستگاه و بهبود نتیجه کار خواهد شد.
توجه داشته باشید که این ابزار نیاز به روغن کاری روزانه یا ساعتی ندارد.

0034 Db




- | | |
|--------------------------------------|---------------------------|
| ۱ - کلید روشن / خاموش | ۷ - خط کش تنظیم عمق |
| ۲ - کلید کنترل سرعت | ۸ - دسته کمکی |
| ۳ - اهرم تغییر دور (سرعت) گیربکس | ۹ - محل ورود هوا |
| ۴ - قفل کن کلید | ۱۰ - محل خروج هوا |
| ۵ - اهرم تغییر حالت (دریل/دریل چکشی) | ۱۱ - شستی چپگرد - راستگرد |
| ۶ - سه نظام آچار خور | ۱۲ - لاستیک کابل |

0034 D




- | | |
|--------------------------------------|---------------------------|
| ۱ - کلید روشن / خاموش | ۷ - خط کش تنظیم عمق |
| ۲ - کلید کنترل سرعت | ۸ - دسته کمکی |
| ۳ - اهرم تغییر دور (سرعت) گیربکس | ۹ - محل ورود هوا |
| ۴ - قفل کن کلید | ۱۰ - محل خروج هوا |
| ۵ - اهرم تغییر حالت (دریل/دریل چکشی) | ۱۱ - شستی چپگرد - راستگرد |
| ۶ - سه نظام آچار خور | ۱۲ - لاستیک کابل |

0022 Da




- | | | |
|----------------------|-------------------------|--------------------------------------|
| ۱- کلید روشن / خاموش | ۵- محل ورود هوا | ۹- خط کش تنظیم عمق |
| ۲- کلید کنترل سرعت | ۶- محل خروج هوا | ۱۰- اهرم تغییر حالت (دریل/دریل چکشی) |
| ۳- قفل کن کلید | ۷- شستی چپگرد - راستگرد | ۱۱- لاستیک کابل |
| ۴- سه نظام اتوماتیک | ۸- دسته کمکی | |

0022 D BMC




- | | | |
|----------------------|-------------------------|--------------------------------------|
| ۱۔ کلید روشن / خاموش | ۵۔ محل ورود هوا | ۹۔ خط کش تنظیم عمق |
| ۲۔ کلید کنترل سرعت | ۶۔ محل خروج هوا | ۱۰۔ اهرم تغییر حالت (دریل/دریل چکشی) |
| ۳۔ قفل کن سوئیچ | ۷۔ شستی چپگرد - راستگرد | ۱۱۔ لاستیک کابل |
| ۴۔ سه نظام آچار خور | ۸۔ دسته کمکی | |

0022 D



- | | | |
|----------------------|-------------------------|--------------------------------------|
| ۱- کلید روشن / خاموش | ۵- محل ورود هوا | ۹- خط کش تنظیم عمق |
| ۲- کلید کنترل سرعت | ۶- محل خروج هوا | ۱۰- اهرم تغییر حالت (دریل/دریل چکشی) |
| ۳- قفل کن کلید | ۷- شستی چپگرد - راستگرد | ۱۱- لاستیک کابل |
| ۴- سه نظام آچارخور | ۸- دسته کمکی | |

0002 Da




۷ - شستی چپگرد - راستگرد
۸ - لاستیک کابل

۴ - سه نظام اتوماتیک
۵ - محل ورود هوا
۶ - محل خروج هوا

۱ - کلید روشن / خاموش
۲ - کلید کنترل سرعت
۳ - قفل کن کلید

0002 D




۷ - شستی چپگرد - راستگرد
۸ - لاستیک کابل

۴ - سه نظام آچار خور
۵ - محل ورود هوا
۶ - محل خروج هوا


۱ - کلید روشن / خاموش
۲ - کلید کنترل سرعت
۳ - قفل کن کلید

0071 D




- | | | |
|--------------------------|---------------------|-----------------|
| ۱ - کلید روشن / خاموش | ۴ - سه نظام آچارخور | ۷ - لاستیک کابل |
| ۲ - قفل کن کلید | ۵ - محل ورود هوا | |
| ۳ - شستی چپگرد - راستگرد | ۶ - محل خروج هوا | |


0034 Db	0034 D	0022 Da	0022 D BMC	0022 D	0002 Da	0002 D	0071 D	مدل پارامتر
۱۰۵۰	۱۰۵۰	۷۵۰	۷۵۰	۷۵۰	۴۰۰	۴۰۰	۳۰۰	توان خروجی (وات)
۱۲۰۰ ۲۸۸۰	۱۲۰۰ ۲۸۸۰	۰-۲۸۰۰	۰-۲۸۰۰	۰-۲۸۰۰	۰-۲۷۰۰	۰-۲۷۰۰	۰-۳۸۰۰	سرعت در حالت بی باری (دور بر دقیقه)
۱۹۲۰۰ ۴۴۸۰۰	۱۹۲۰۰ ۴۴۸۰۰	۴۴۸۰۰	۴۴۸۰۰	۴۴۸۰۰	-	-	-	تعداد ضربه (ضربه بر دقیقه)
۱/۵-۱۳	۱/۵-۱۳	۱/۵-۱۳	۱/۵-۱۳	۱/۵-۱۳	۱/۵-۱۰	۱/۵-۱۰	۰/۵-۶/۵	سایز سه نظام (میلیمتر)
۴۰	۴۰	۳۰	۳۰	۳۰	۲۰	۲۰	۱۰	حداکثر قطر سوراخ کاری در چوب (میلیمتر)
۱۳	۱۳	۱۳	۱۳	۱۳	۱۰	۱۰	۶/۵	حداکثر قطر سوراخ کاری در فولاد (میلیمتر)
۲۰	۲۰	۱۶	۱۶	۱۶	توصیه نمی شود	توصیه نمی شود	توصیه نمی شود	حداکثر قطر سوراخ کاری در بتن (میلیمتر)
۲/۹	۲/۹	۲	۲/۱	۲/۱	۱/۴	۱/۴	۱/۱	وزن دستگاه (کیلوگرم)




0002 Da




0002 D




0071 D




0022 Da




0022 D BMC



0022 D



0034 Db



0034 D

قبل از آغاز به کار با دستگاه، از نصب صحیح مته، خط‌کش تنظیم عمق و دسته کمکی مطمئن شوید.

پیش از تنظیم دستگاه یا بررسی وضعیت عملکرد آن، از خاموش بودن دستگاه اطمینان حاصل نمایید.

برای استفاده از دستگاه، ابتدا آن را روشن کرده و صبر کنید تا به دور استاندارد (نرمال) برسد. از روشن کردن دستگاه بر روی سطح کار، اکیدا خودداری کنید، این امر احتمال آسیب رسیدن به کاربر را افزایش می‌دهد.

در صورت بروز مشکلاتی اعم از قطع شدن کلید، بوی سوختگی، نوسان (قطع و وصل شدن)، لرزش و... که عملکرد عمومی دستگاه را مختل نموده است، دستگاه را خاموش نموده و با خدمات پس از فروش تماس حاصل فرمایید. (شماره‌های تماس در ضمانت-نامه موجود است)

پس زدن، گیرکردن یا ضربه زدن، یک واکنش ناگهانی است که در نتیجه گیرکردن ابزار و متعلقات در حال چرخش، به وجود می‌آید. بدین ترتیب ابزار به طور ناگهانی متوقف شده، از کنترل کاربر خارج می‌گردد و امکان مدمه به کاربر وجود دارد. لذا جهت مهار مناسب ابزار، وضعیت تعادل خود را حفظ نموده و مطمئن شوید فضای مناسبی برای ایستادن انتخاب کرده‌اید. این امر موجب می‌شود تا کاربر علاوه بر حفظ تعادل خود، کنترل بهتری بر ابزار داشته باشد.

هنگام کار با ابزار، آن را محکم و به‌درستی در دست بگیرید تا قادر به کنترل و خنثی نمودن نیروهای واکنشی از سوی دستگاه باشید.

دسته دستگاه را خشک، تمیز و عاری از روغن و گریس نگه‌دارید.

استفاده طولانی مدت از ابزارهای قدرتی (یا دستگاه‌های دیگر) که اپراتور را در معرض ارتعاشات قرار می‌دهد، ممکن است منجر به آسیب رسیدن به دست کاربر شود.

هرگز ابزار را در مواقع غیرضروری، بدون بار روشن نکنید.

مته کند و بی‌کیفیت، علاوه بر افزایش زمان سوراخ‌کاری، موجب انتقال ارتعاشات بیشتری به دست کاربر خواهد شد.

طول عمر ابزار و استفاده بهینه از آن، مشروط به رعایت دستورات کاربردی و استفاده از ملزومات مناسب و قطعات اصلی می‌باشد. استفاده از متعلقات غیر استاندارد و متفرقه، احتمال آسیب به کاربر و دستگاه را افزایش می‌دهند.

در صورت نیاز به قطعات مصرفی، حتما از قطعات متناسب با مدل دستگاه استفاده نمایید. تجهیز ابزار با قطعات اصلی، طول عمر و ایمنی دستگاه شما را تضمین می‌نماید.

ایمنی الکتریکی

پریز مورد استفاده برای این ابزار، می‌بایست متناسب با دوشاخه آن باشد. از ایجاد هرگونه تغییر در دوشاخه، جدا خودداری فرمایید و هرگز از تبدیل دوشاخه، برای ابزار برقی دارای ارت استفاده نکنید. دوشاخه استاندارد و پریز منطبق با آن، خطر برق گرفتگی را کاهش می‌دهد.

از قرار دادن ابزار برقی در مجاورت باران و رطوبت خودداری کنید. نفوذ آب و رطوبت به آن، خطر برق گرفتگی را افزایش می‌دهد.

هیچگاه دوشاخه را با کشیدن کابل، از پریز جدا نکنید. جهت حفظ ایمنی، کابل را به دور از حرارت، روغن، لبه‌های تیز و قطعات متحرک نگه دارید. همواره از سلامت و عدم پارگی کابل اطمینان حاصل کنید، کابل آسیب دیده یا تاب خورده خطر شوک الکتریکی را افزایش می‌دهد.

زمانی که از ابزار برقی در محیط باز استفاده می‌کنید، حتماً از سیم‌سیار مناسب و استاندارد استفاده نمایید. استفاده از سیم‌سیار مناسب خطر برق گرفتگی را کاهش می‌دهد.

ایمنی محیط کار

نور کافی موجب تسریع در انجام کار و جلوگیری از حوادث احتمالی می‌گردد. از ابزار برقی در محیط‌هایی با خطر انفجار، نظیر مجاورت مایعات قابل اشتعال و گازها استفاده نکنید.

استفاده صحیح از ابزار و مراقبت‌های حین کار

با توجه به ظرفیت ثابت هر دستگاه، از اعمال نیروی بیش از حد بر دستگاه خودداری کرده و همواره برای هر کار، از ابزار مناسب استفاده نمایید. هر ابزار وظیفه‌ای خاص به-عهده داشته و نمی‌توان از یک دستگاه، انتظار چند نوع کار را داشت. به‌خاطر داشته باشید، هر ابزار به‌منظور عملکرد خاصی، طراحی و تولید می‌شود. با توجه به وجود قطعات و اجزاء حساس در این ابزار، از سقوط ابزار یا وارد شدن ضربه به آن ممانعت نمایید.

هرگز اجازه استفاده از ابزار را به افراد ناآگاه و بدون تخصص ندهید. قبل از کار با دستگاه، می‌بایست دفترچه راهنما به دقت مطالعه شود. از مهمترین کاربردهای این ابزار، سوراخ کاری سطوح مختلف است.

نحوه بکارگیری دفترچه راهنما

هدف از تدوین دفترچه راهنما، ارائه نکاتی برای استفاده بهینه از ابزار بوده و سعی شده است که نکات مهم ایمینی، عملکردی و نحوه نگهداری از ابزار، به طور کامل توضیح داده شود.

پیشنهاد می گردد، قبل از شروع به کار، این دفترچه را به دقت مطالعه فرمایید و آن را در حین کار به همراه داشته باشید.
در صورت نیاز به اطلاعات خدمات پس از فروش و سرویس های دوره ای، ضمانت نامه محصول را مطالعه نمایید.

ایمینی عمومی کار با ابزار

منظور از ابزار، صرفاً ابزارهای برقی می باشد.
هشدارها، نمادها و دستورالعمل های مندرج در دفترچه راهنما را به دقت مطالعه نموده و درک کنید. عدم رعایت این دستورالعمل ها ممکن است کاربر را دچار آسیب و صدمات جدی نماید.

ایمینی فردی

قبل از شروع به کار با دستگاه، اطمینان حاصل نمایید که توانایی کار با آن را دارید. با حواس جمع و دقت بالا کار کنید. بی توجهی کاربر می تواند منجر به آسیب های جبران ناپذیری شود.

همواره از تجهیزات ایمینی مطابق با شرایط کار استفاده نمایید. استفاده از عینک ایمینی، ماسک، کلاه ایمینی، کفش و لباس ایمینی و... صدمات و خطرات احتمالی کار را کاهش می دهد.

قبل از رها کردن ابزار، مطمئن شوید که دستگاه به طور کامل خاموش شده است و آن را در محل مناسبی قرار داده اید.

تجهیزات و لوازم جانبی را به طور دقیق و صحیح بر روی دستگاه نصب کنید و از آماده به کار بودن آن اطمینان حاصل نمایید.

جهت مهار مناسب ابزار، وضعیت تعادل خود را حفظ نموده و مطمئن شوید فضای مناسبی برای ایستادن انتخاب کرده اید. این امر موجب می شود تا کاربر علاوه بر حفظ تعادل خود، کنترل بهتری بر ابزار داشته باشد.

پیش از اتصال دستگاه به جریان برق، از خاموش بودن کلید برق مطمئن شوید.
در صورتی که ابزار در اثر حمل و جابجایی یا کاربری نادرست آسیب دیده است، پیش از استفاده از آن، به خدمات پس از فروش مراجعه نمایید.

فهرست

عنوان	صفحه
نحوه بکارگیری دفترچه راهنما	۱
ایمنی عمومی کار با ابزار	۱
ایمنی فردی	۱
ایمنی الکتریکی	۲
ایمنی محیط کار	۲
استفاده صحیح از ابزار و مراقبت های حین کار	۲
جدول های فنی	۴
اجزاء دستگاه	۵
قبل از شروع	۱۳
راه اندازی	۱۳
حمل و جابجایی ابزار	۱۴
نگهداری در شرایط انبار، فصول مختلف سال و	۱۴
شرایط اسقاط کردن محصول	



MERIT LINK INTERNATIONAL AG
P.O. Box 641, CH-6855 Stabio
Switzerland
www.meritlink.com